

FAQ'S

IS THERE A RIGHT AND A LEFT TO THIS FIN?

The Positive Drive Fin is molded as a single fin. Both fins in the box are identical, so while technically there is no right or left fin, there is a correct way to wear the fins. The fins should be oriented with the wider portion of the blade on the outer portion of your foot. On your right foot you will see the FINIS logo, on the left you will see the fin size imprinted on the blade of the fin.

MY FINs ARE IN GREAT SHAPE BUT THE STRAP HAS BROKEN, DO YOU SELL REPLACEMENTS?

We do offer replacement straps for the Positive Drive Fin (PDF) and they are available in the Accessories tab on FINISinc.com