

## **QUALITY AND PERFORMANCE THAT'S AFFORDABLE!**

Branick has been making spreaders for almost 80 years. We have channeled all that experience into our line of small spreaders. You're sure to find the right fit for your shop with features like sawtooth or spring set adjustment, zinc plated rollers, air powered or gas spring assisted spread arms, and an RMA compliant gooseneck LED light. From the entry model 5035 to the heavier 5120, all are designed to handle any passenger and light truck tire up to 20". The 5120 can even take 22.5" tires. All include a solid 4 point base that can be bolted to the floor for added stability If you're thinking of adding a spreader, think Branick. Manufactured at Branick's facility in Fargo, ND means you get American made quality and toughness.

www.branick.com 4245 Main Ave Fargo, ND 58107 Phone: 800.437.4394 Fax: 701.281.5900



Light Truck

,	Specifications	5025	5035	5045	5120
	Maximum Bead Diameter	20"	20"	20"	22.5"
	Maximum Tire X-Section	12" / 305 mm	13.5" / 343 mm	13.5" / 343 mm	14" / 356 mm
	Spread Arm Type	Manual	Manual	Gas Spring Assist	Air Powered
	Spread Arm Operation	Hand	Hand	Hand	Foot
	Working Height	35"	36.25"	36.25"	36"
	Light	No	LED	LED	LED
	Roller	No	No	Yes	Yes
	Hook Adjustment	Sawtooth	Sawtooth	Sawtooth	Spring Locking Pin
	Tool Tray	No	No	No	Yes
	Shipping Wieght	30	78	80	150
	Dimensions	10 W x 10 D x 36 L	22 W X 15 D X 45 L	22 W X 15 D X 45 L	29 W X 27 D X 40 L

## Storage Cabinet (available on 5035 & 5045)

Keep your repair and inspection tools where you need them, at the spreader. Our optional storage cabinet attaches directly to either side of the spreader so you won't waste time searching for supplies. Steel construction to take the punishment of a shop environment.



If you need a little extra height for an ergonomic position, the optional riser platform will do the trick. The platform's 3" lift brings the working surface to 39.25". Bolts directly to the base of the spreader and includes pre-drilled holes for floor mounting.



The Model 502 base gives the 5025 the stability to work without bolting to the floor, allowing the spreader to be moved wherever it's needed. Easy four bolt installation.





