

# Commercial-Duty Wrench Support Stand

Use to support impact wrench, torque wrench,  
double-end truck wrench or 4-way lug wrench  
when removing or replacing lug nuts

## Warning:

This tool is to be used as a lug nut wrench support **only**.  
Do not use when any components are damaged.  
Maximum load 300lbs.

## Instructions:

Put wrench on lug nut.  
Raise support to wrench height so wrench is cradled in the stand.  
Position wrench/leverage bar at horizontal angle with ground  
Push down on one side of the wrench/leverage bar to break the lug nut loose or  
to tighten the lug nut.  
Continue with the same process until all lug nuts have been loosened or  
tightened.