



# Models 1800, 1842, 1842E, 1844, 1844E PowerLuber Grease Gun

## Service Parts List

Item	Description	Part Number
1	FLEXIBLE HOSE 30" W/GASKET (MODELS 1800, 1842, 1844)	1230
	FLEXIBLE HOSE 30" W/GASKET (MODELS 1842E, 1844E)	1230E
2	COUPLER (MODELS 1800, 1842, 1844)	5852
	COUPLER (MODELS 1842E, 1844E)	251-10124-7
3	PACKING	34793
4	FOLLOWER ASSEMBLY KIT	93485
5	GREASE TUBE ASSEMBLY	271882
6	GASKET KIT (HOSE)	271884
7	SEAL	271889
8	HANDLE KIT (GREASE TUBE)	286090
9	ROD, FOLLOWER KIT	286091
10	HOSE CLIP KIT	286092
11	COUPLER CAP KIT	286093
12	TRIGGER KIT	286215
13	TERMINAL ASSEMBLY KIT	286096
14	GEAR SELECTOR KIT	286216
15	HANDLE HARDWARE	286100
16	DECAL KIT	286219
17	MOTOR WITH PLATE	286221
18	PUMP HARDWARE	286105
19	COVER PUMP KIT	286106
20	YOKE KIT	286107
21	STROKE INDICATOR	286108
22	PLUNGER KIT	286109
23	STUD KIT	286110
24	ROLLER	286111
25	SPRING SELECTOR	286113
26	VENT/BULK VALVE KIT	286134
27	CIRCUIT BREAKER 15A© KIT	286409©
28	DRIVER ASSEMBLY	286285
29	GEAR SET KIT	286286
30	HANDLE WITH ELECTRICAL COMPONENT KIT	286323
31	HANDLE WITH SCREW KIT	286324
32	PUMP ASSEMBLY KIT	286326
33	CHECK VALVE KIT	286306
34	HOUSING PUMP WITH BEARING	286307
35	VENT VALVE KIT	286315
36	GASKET KIT (RELIEF VALVE)	286316
37	RELIEF VALVE KIT	286317
38	BATTERY 18V	1801
	CHARGER	1410
	STRAP	1414

© Indicates change