


TANK TO BOWL KIT

Installation Instructions:

1. Slip tank to bowl gasket onto flush valve threads.
2. Place rubber washer on bolt and insert through the hole in tank.
3. Place a metal washer and hex nut onto bolt and hand tighten.
4. Put tank onto bowl and then slip rubber washer and metal washer onto bolt with wing nut and finger tighten wing nut. Do this for all bolts, keeping tank level.

Note: Do not overtighten bolts!



JUEGO TANQUE-TAZA

Instrucciones de Instalación:

1. Pase la arandela tanque-taza en las roscas de la válvula de descarga.
2. Coloque la arandela de goma en el perno e insértelo a través del orificio del tanque.
3. Coloque la arandela metálica y la tuerca hexagonal en el perno y ajuste a mano.
4. Ponga el tanque sobre la taza y luego pase la arandela de goma y la de metal en el perno con la tuerca de ala y ajuste con los dedos. Repita para todos los tornillos, manteniendo el tanque nivelado.

Nota: ¡No ajustar demasiado los pernos!

