



SD72, SD72W, SD72WV

INSTALLATION INSTRUCTIONS

1. Use two wire nuts to attach the appropriate transformer wires to the field wiring.
2. Cut off the bare portion of the un-used leads.

Hardware Reference:

Model **SD72** Mounts to all Atlas Sound 8" baffles except FA series

Models **SD72W** & **SD72WV** are compatible with the following Atlas Sound hardware items:

Mounting Rings: 75-8(E2), 76-8(E2), P77-8, P78-8

T-Bridges: 81-8R, 81-8S

Enclosures: (EZ)95-8 Series, T95-8 Series, Q408, CS95-8, BMT95-8, BMT95-8-7

TAP WATTAGE	70.7V
0.25	Red
0.5	White
1	Yellow
2	Blue
5	Brown
COMMON	BLACK

TAP WATTAGE	25V
0.25	Blue
0.5	Gray
1	White/wGreen
2	Violet
5	Orange
COMMON	BLACK

Frequency Response: 55Hz-8kHz

Sensitivity: 97dB (1W/1M)

Specifications are subject to change without notice



AtlasSound.com

1601 JACK MCKAY BOULEVARD ENNIS, TEXAS 75119 U.S.A. • TELEPHONE: (800) 876-3333 • FAX: (800) 765-3435

©2003 ATLAS SOUND LP

Printed in China

00303

ATS001198 RevC 3/03

PP



SD72, SD72W, SD72WV

INSTALLATION INSTRUCTIONS

1. Use two wire nuts to attach the appropriate transformer wires to the field wiring.
2. Cut off the bare portion of the un-used leads.

Hardware Reference:

Model **SD72** Mounts to all Atlas Sound 8" baffles except FA series

Models **SD72W** & **SD72WV** are compatible with the following Atlas Sound hardware items:

Mounting Rings: 75-8(E2), 76-8(E2), P77-8, P78-8

T-Bridges: 81-8R, 81-8S

Enclosures: (EZ)95-8 Series, T95-8 Series, Q408, CS95-8, BMT95-8, BMT95-8-7

TAP WATTAGE	70.7V
0.25	Red
0.5	White
1	Yellow
2	Blue
5	Brown
COMMON	BLACK

TAP WATTAGE	25V
0.25	Blue
0.5	Gray
1	White/wGreen
2	Violet
5	Orange
COMMON	BLACK

Frequency Response: 55Hz-8kHz

Sensitivity: 97dB (1W/1M)

Specifications are subject to change without notice



AtlasSound.com

1601 JACK MCKAY BOULEVARD ENNIS, TEXAS 75119 U.S.A. • TELEPHONE: (800) 876-3333 • FAX: (800) 765-3435

©2003 ATLAS SOUND LP

Printed in China

00303

ATS001198 RevC 3/03

PP