

ASSEMBLE

Locate section A and section B of the paddle. Check that the latch at the top of section B is in the open position. Insert the bottom of section A into the latch fitting of section B. Determine your desired paddle length and align the corresponding measurement on section A with the arrow on the top of the latch. Close the latch, securing section A into place.

Next, attach section C to the bottom of section B using the spring-button. While holding down the spring-button located near the bottom of section B, slide the pole into the top of section C, aligning the spring-button with the hole near the top of section C. The button will pop into place, securing section C to section B.

Now, all three sections are secured into place and ready for the water!

ADJUST

The 3-Piece Adjustable Stand-Up Paddle Board Paddle is designed to provide accessible fun for paddlers at any skill level. By opening the latch on section B, the length of the paddle can easily be adjusted from 67-in to 83-in to accommodate all users.

DISASSEMBLE

Designed for easy transport and storage, this three-piece paddle can quickly be broken down into 3 pieces and packed into your luggage or inflatable SUP bag.

To disassemble, push in the spring-button section B while pulling sections B and C apart. Next, open the latch on section B and pull sections A and B apart.

**1-YEAR WARRANTY**

Your SUP paddle comes with a 1-year limited warranty. We promise that it will arrive damage free with all necessary parts and accessories. Otherwise, we'll send replacement parts or an entirely new unit to you at no cost.