


AIR CLEANER

SPT®



Intertek

AC-2062

AIR CLEANER

user manual

Thank you for your purchase of this new SUNPENTOWN product. Please read thoroughly and retain this manual for future references.

CAUTION:

1. This appliance is intended for household only.
2. Never operate this unit if the cord is damaged. In case of damage, the cord must be replaced by the manufacturer, an authorized service agency or a similarly qualified electrician.
3. Close supervision is necessary when this item is used by or near children.
4. The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of appliance by a person responsible for their safety.

1

IMPORTANT SAFETY INSTRUCTIONS


Please read all instructions before using this product. Save these instructions for easy reference. When using electrical appliances basic precautions should always be followed to reduce breakage, risk of fire, electric shock and injury to persons including the following:

- Read all instructions before operating the air cleaner.
- Place the air cleaner where it is not easily knocked over by persons in the household.
- ALWAYS unplug air cleaner when not in use.
- DO NOT use any product with a damaged cord or plug, or if product malfunctions, is dropped or damaged in any manner.
- Keep the power cord away from heated surfaces.
- DO NOT use air cleaner outdoors.
- NEVER use the air cleaner unless it is fully assembled.
- DO NOT run power cord under carpets and DO NOT cover with throw rugs. Arrange cord so it will not be tripped over.
- DO NOT use air cleaner where combustible gases or vapors are present.
- DO NOT expose the air cleaner to rain, or use near water, in a bathroom, laundry area or other damp locations.
- To disconnect air cleaner, first turn the unit off by pressing the Power Button, then remove plug from outlet.
- DO NOT allow foreign objects to enter ventilation or exhaust openings, as this may cause electric shock or damage to the air cleaner.
- Place air cleaner near a power outlet and avoid using an extension cord.
- DO NOT block air outlets or intakes.
- To reduce risk of electric shock, this equipment has a grounding type plug that has a third (grounding) pin. This plug will only fit into a grounding type power outlet. If the plug does not fit into the outlet, contact qualified personnel to install the proper outlet. Do not alter the plug in any way.
- The air cleaner has a 3-prong (grounded) plug for safe operation. The 3-prong plug should be plugged directly into a properly grounded 3-prong electrical outlet. DO NOT, FOR ANY REASON WHATSOEVER, CUT OR REMOVE THE GROUNDING PRONG FROM THE PLUG. Removing the grounding plug may result in electrical shock or create unsafe condition. Contact a qualified electrician to be sure the outlet is properly grounded.
- A loose fit between the plug and the AC outlet (receptacle) may cause overheating and distortion of the plug. Contact a qualified electrician to replace loose or worn receptacles.
- DO NOT sit, stand on, or place heavy objects on the air cleaner.
- ALWAYS disconnect power supply before servicing.

WARNING! To reduce the risk of fire or electric shock, DO NOT use this product with any solid-state speed control device.


2

PART LIST



3

OPERATION



ON/OFF

ON/OFF

- Press to turn on the air cleaner.
- Press again to turn off.



Ionizer

IONIZER

- Press the button to turn on the ionizer.
- Press again to turn off the ionizer.



Speed

SPEED

- Press to select cleaning level. The air cleaner offers 3 speeds:
H (high): Maximum operation = Fast cleaning
M (medium): Daytime operation = Normal cleaning
L (low): Nighttime operation = Quieter cleaning



Timer

TIMER

- Press to operate the air cleaner for a set duration of 1 hour, 2 hours or 4 hours.
- When the set time is up, the air cleaner will turn off automatically.
- Press again to cancel timer.




Filter Reset

FILTER RESET button and indicating lights.

- When the HEPA indicator light is illuminated, it means your current HEPA filter has worked for 2,800 hours and needs to be replaced.
- When the VOC indicator light is illuminated, it means your current VOC filter has worked for 1,400 hours and needs to be replaced.
- Once the filter replacement is done, press and hold the button for 3 seconds to reset the filter lifetime calculation.

4

REPLACING FILTERS



When the HEPA indicator light on the control panel is illuminated, it means your current HEPA filter has worked for 2,800 hours and needs to be replaced.

When the VOC indicator light on the control panel is illuminated, it means your current VOC filter has worked for 1,400 hours and needs to be replaced.

Steps to replace the filters:

1. Turn off the air cleaner by pressing the power button. Then unplug the unit from the electrical outlet.
2. On the rear cover, locate the release tabs on each side, gently pull and remove cover.
3. Remove and discard any plastic protective wrapping from the new filter(s).
4. Replace the old filter with a new one.
Placement: HEPA filter, the arrows face inward (toward the machine).
Placement: VOC filter, the pull tabs face outward (toward you).
5. Reposition the rear cover (bottom tabs should engage into the slots at the base of the unit first)
6. Turn on the unit.
7. Press and hold the FILTER RESET button until the indicator light(s) goes off (about 3 seconds). The filter lifetime calculation is reset.

Note:

- Make sure to turn off the power and unplug the unit before replacing the filters.
- Neither the HEPA Filter nor VOC Filter is washable.
- Never operate the air cleaner until it is completely and fully assembled.

5 MAINTENANCE

CAUTION: To ensure performance, this equipment should be inspected frequently and collected dirt removed regularly. This also prevents excessive accumulation that may result in flashover or a risk of fire.

1. Turn the air cleaner off and unplug from the outlet.
2. Use a soft damp cloth to gently wipe the external surface. DO NOT pour or splash water on the unit or use abrasive cleaners.

DO NOT attempt to clean the HEPA filter or VOC filter with liquids, they ARE NOT washable. Any attempts to wash them will damage the filters.

6 SPECIFICATIONS

- Dimensions: 10.35 x 7.68 x 25.39 in. (L x W x H)
- Weight: 11 lbs.
- Input voltage: 120V AC / 60Hz

7 REPLACEMENT PARTS

- HEPA Filter: 2062-HEPA
- VOC Filter: 2062-VOC

8

YOUR GUARANTEE

If this product is found to be faulty as a result of faulty materials or workmanship within one year from date of purchase, it will be repaired free of charge.

This guarantee is subject to the following terms:

- Sunpentown must be notified of the fault.
- Proof of purchase must be presented to Sunpentown's nominated representative.
- The warranty will be void if the product is modified, misused or repaired by an unauthorized person.
- The warranty after repair will not be extended beyond the original one-year period.
- All replacement parts will be new or reconditioned.
- Parts, which are replaced, become the property of Sunpentown.
- The warranty applies for the use of the product in the USA only.

What is NOT COVERED:

- Warranty does not include freight charges.
- Incidental or consequential damage caused by possible defects with this product.
- Damage to product caused by improper power supply voltage, accident, fire, floods or acts of nature.
- Failure of product resulting from unauthorized modifications to the product.
- Improper installation or failure to perform the necessary maintenance.

This GUARANTEE is in addition to your Statutory Rights

SUNPENTOWN INTERNATIONAL INC.
14625 Clark Ave, City of Industry, CA 91745
Tel: 1-800-330-0388
service@sunpentown.com
www.sunpentown.com