INSTRUCTIONS

- Connect battery (12V only) to the terminal identified with a "+" tag.
- 2. Ground the terminal with a "-" tag. 3. Your switch panel is supplied with 6 (WARNING: DO not, use fuse rated over 15A). First decide what rating of fuse should be used for each switch. fuses -6x5A.
- To remove the fuseholder cap, see diagram below:







"PUSH↑" indicates slot the fuseholder body.

Press downward. screw insert a ball pen or small driver in the slot.

remove fuse, čap back to Cap pops out. Insert or position. then snap

Fuse bar is positive (+)
Switch bar is negative (-)
Center tap on switch goes to positive (+) on appliance
*Make sure negative (-) of appliance is connected (-) on same ground
The negative wire (-) or ground wire (-) on the appliance must be connected to a common negative ground (-) on the instrument panel.

Example-negative terminal ammeter.

