

Gelcoat Finishing - Retail Multi-Step			Product List		
1	Cleaning		Wash the surface with boat soap.		<ul style="list-style-type: none"> <li>• 3M™ Marine Boat Soap, PN 09034, 16 oz., bottle</li> <li>• 3M™ Perfect-It™ Detail Cloth, PN 06016, 6 cloths/bag</li> </ul>
2	Sanding		Wet sand the gelcoat surface with an Ultrafine Softback Sanding Sponge to remove surface oxidation. Apply medium pressure when sanding the oxidized gelcoat surface.		<ul style="list-style-type: none"> <li>• 3M™ Softback Sanding Sponge, PN 02600, 4 ½ in. x 5 ½ in., Microfine</li> </ul>
3	Buffing		Buff the sanded gelcoat area with 3M™ Marine Color/Gloss Restorer to remove sand scratches. Use a white wool buffing pad with the 3M™ Marine Color/Gloss Restorer. Set the buffer speed between 1600 and 2000 rpm's.		<ul style="list-style-type: none"> <li>• 3M™ Marine Color/Gloss Restorer, PN 09089, 500 mL., bottle</li> <li>• 3M™ Perfect-It™ 100% Wool Compound Pad, PN 05753, double sided, quick connect</li> <li>• 3M™ Quick Connect Adaptor, PN 05752, 5/8 in. thread</li> <li>• 3M™ Electric Variable Speed Polisher, PN 28391, 7 in. 11A 5/8-11 EXT, 1 per case</li> <li>• 3M™ Perfect-It™ Low Lint Wool Compound Pad, PN 33288, 6 in.</li> </ul>
4	Polishing		Polish the repaired area with restorer and wax. Use a yellow wool polish pad. Set the buffer speed between 1600 and 2000 rpm's.		<ul style="list-style-type: none"> <li>• 3M™ Marine Restorer and Wax, PN 09005, 16 fl oz., bottle</li> <li>• 3M™ Polishing Pad, PN 05705</li> <li>• 3M™ Perfect-It™ Wool Polishing Pad, PN 05754, 9 inch</li> <li>• 3M™ Electric Variable Speed Polisher, PN 28391, 7 in. 11A 5/8-11 EXT, 1 per case</li> </ul>
5	Protection		Protect the repaired area with marine wax. Apply marine wax by hand using a microfiber detail cloth in sections no larger than a 2' x 2' area. Do not let the marine wax dry on the gelcoat. Wipe the film off before the wax dries.		<ul style="list-style-type: none"> <li>• Scotchgard™ Marine Liquid Wax, PN 09061, 500 mL., bottle</li> <li>• 3M™ Perfect-It™ Detail Cloth, PN 06016, 6 cloths/bag</li> </ul>



### Think About Your Health



3M™ E-A-R™ Skull Screws™ Ear Plug, PN P1300



3M™ Half Facepiece Respirator, PN 07182



3M™ Lexa™ Protective Eyewear, PN 15200