


# Single Monitor Extra Tall Desk Mount

Instruction Manual



# SKU: STAND-V001T



Scan the QR code with your mobile device or follow the link for helpful videos and specifications related to this product.

https://vivo-us.com/products/stand-v001t







# **№** WARNING!

If you do not understand these directions, or if you have any doubts about the safety of the installation, please call a qualified technician. Check carefully to make sure there are no missing or defective parts. Improper installation may cause damage or serious injury. Do not use this product for any purpose that is not explicitly specified in this manual. Do not exceed weight capacity. We cannot be liable for damage or injury caused by improper mounting, incorrect assembly or inappropriate use.

# <u>^</u>

## **TIPOVER WARNING**


SERIOUS OR FATAL CRUSHING INJURIES CAN OCCUR FROM TIPOVER. TO HELP PREVENT TIPOVER:

- NEVER ALLOW CHILDREN TO CLIMB, STAND, HANG, OR PLAY ON ANY PART OF MONITOR OR STAND.
- USE TIPOVER RESTRAINT OR ANCHOR STAND TO WALL

USE OF TIPOVER RESTRAINTS MAY ONLY REDUCE, BUT NOT ELIMINATE RISK OF TIPOVER.

# **⚠** WARNING: CHOKING HAZARD

SMALL PARTS - NOT FOR CHILDREN UNDER 3 YEARS. ADULT SUPERVISION IS REQUIRED.



NOTE: NOT ALL HARDWARE INCLUDED WILL BE USED

#### **TOOLS NEEDED**



DO NOT EXCEED WEIGHT CAPACITY.

Failure to do so may result in serious injury.


(7.98kg)

## **ASSEMBLY STEPS**

#### STEP 1


#### **OPTION A: "C" Clamp Installation**

Slide the cable management clip (**G**) and base cover (**H**) on to the bottom pole (**B**). Thread the bottom pole (**B**) onto the clamp (**D**). Tighten the grub screws into the bottom of the clamp (**D**) using 3mm allen wrench (**K**). Secure the clamp (**D**) to the desktop as shown in diagram.




#### **OPTION B: Existing Grommet Hole Installation**


Remove the screw from the top of the bolt in the clamp (**D**). Stick the soft pads (**I**) to the bottom of the grommet base (**E**).




# STEP 1 (continued)




### STEP 2



#### STEP 3




#### STEP 4




4


# STEP 4 (continued)



## STEP 5



## STEP 6





If any parts are received damaged or defective, please contact us. We are happy to replace parts to ensure you have a fully functioning product.







help@vivo-us.com

www.vivo-us.com

1-800-371-5654

For more VIVO products, check out our website at: www.vivo-us.com.