



HD Cross Over Steering System.

P/N: 18050.82 (XJ-TJ-ZJ) 18050.83 (1987-1995 YJ)

NOTE: In some applications where factory Jeep® rims are used with larger tires, slight rubbing of passenger side tire against the H/D Tie-Rod tube Tie-Rod end may be experienced. Smaller 7" steel YJ wheels should not be used. Check fitment prior to installation.

All responsibility for inspecting, installing, tightening, and the application of proper OE torque specifications rest solely with the owner. These steps are vital to prevent the loosening of components. It is the owner's responsibility to be aware that with the addition of larger tires, suspension upgrades, and steering modifications the vehicles handling characteristics can be dramatically altered. It is the owner's responsibility to account for these alterations – changes and make corrections where needed.

This kit has been designed as an H/D upgrade for the stock small tube and cast steering linkage when used with larger aftermarket wheels and tires. When properly installed in conjunction with a properly prepared and maintain vehicle steering characteristics should be the same as OE unit. This kit has been designed to extend the drag link as far to one side as possible to help relieve bump steer that can develop in lifted vehicles. The use of a drop pitman arm should also be used to try and make the Tie-Rod tube as parallel (level) as possible.

NOTE: This Kit has been designed for lifts up to 6". For lifts past 6" and are to be used as a daily driver, it is recommended that an over the top steering system be used. This will require modification to the outer knuckles.

With any lift over 2" a drop pitman is recommended.

This kit has been designed to help keep steering links as close to level as possible, but a drop pitman arm may be required to assist in keeping links closer to parallel on lifted vehicles. Because of how the drag link attaches to the passenger side tie-rod slight rotation of the steering linkage (twisting up and down) may be visible when steering wheel is cycled. This will be exaggerated on vehicles with taller lifts as the drag link will want to push down or up, as well as side to side, during its range of movement (This is considered NORMAL) see fig1. It is highly recommended that if any modifications have been made to your vehicle that a qualified 4wd shop and or alignment expert be consulted for final adjustments. Vehicles lifted over 6" may experience difficulty with alignments.

NOTE: It is the owner's responsibility to drive his or her vehicle in a safe and responsible manner at all times. Seat belts and or harnesses should be worn when vehicle is in motion.

It is the owner's responsibility to check that all bolts and or keeper nuts are tight and with in listed torque specs after first 10-20 miles of driving and should be rechecked after 200 miles or after all off-road trips.

Fig. 1



Installation Instructions:

- (1) (ALL) Properly secure vehicle. Place in gear or park and set emergency brake. For further safety block tires.
- (2) (TJ-XJ-ZJ) Remove old steering linkage. DO NOT alter the position of the front wheels or steering wheel during the removal. Keeping these components in the original position will allow you to keep your front end alignment as close to original as possible. Prior to installation run a tape measurer from passenger side knuckle (inner) to Driver's side knuckle (inner) and note length. If knuckles are moved by accident you will be able to return to the correct position by using this measurement. After any steering modification an alignment by a professional shop is recommended.

(YJ 87-95) Remove old steering linkage. It may be necessary to move one wheel – knuckle outbound to remove original steering linkage. Prior to doing this run a tape measurer from passenger side knuckle (inner) to Driver's side knuckle (inner) and note length. You will need this measurement to return your steering to its original position. After any steering modification an alignment by a professional shop is recommended.

- (3) (TJ-XJ-ZJ) Attach H/D Cross-Over steering as shown below (Fig.2A). The dual attachment point tie-rod end (18043.27) should be mounted to the passenger side knuckle. With tubes and tie-rod ends installed turn all keeper nuts full out (Fig.3). By turning the H/D center tubes clock wise or counter clockwise adjustments to the lengths can be made. Adjust until all mounting holes are aligned. Attach castle nuts and torque to 60ft-lbs for all locations. During adjustments it is important to keep the front wheels and pitman arm in the original position.

(YJ 87-95) Insert the new H/D Cross-Over steering. Start at the knuckle that has been moved outbound and slide over leaf springs (Fig.2B). The dual attachment point tie-rod end (18043.28) should be mounted to the passenger side knuckle. Using the measurement taken in step 2 return the wheel & knuckle back to the correct position. With tubes and tie-rod ends installed into knuckles and pitman arm turn all keeper nuts full out (Fig.3). Adjustments to lengths are made by turning the H/D center tubes clock wise or counter clockwise. Adjust until all mounting holes are aligned. Attach castle nuts and torque to 60ft-lbs for all locations. During adjustments it is important to keep the front wheels and pitman arm in the original position.

Fig.2A



Fig.2B



**H/D Cross –Over steering conversion.
P/N: 18050.82 (XJ-TJ-ZJ) 18050.83 (1987-1995 YJ)**

Fig. 3



Fig.4



Fig.5



- (4) (ALL) Double check all castle nuts for proper torque setting and insert cotter pins and grease fittings. Add additional grease if needed. After grease has been inserted remove nipples and insert supplied plugs. These plugs are to reduce damage when used off-road. Attach H/D steering stabilizer bracket and position so that no interference with any other steering component or engine oil pan occurs during full suspension cycle. The brackets damper attachment bar is bent to allow for any number of positions. The bracket may be turned 360degs as the mounting holes are squared to the size of the u-bolts. If your choose to reusing the old damper it's tapered bolt will need to be cut off and the new bolt used that is supplied with the kit. Also the bracket will need to be mounted so that when the Jeep is sitting with wheels straight there is enough movement in the dampener to allow for full left and full right turns with no binding or bottoming out. By not moving the damper's piston during removal you will be able to determine where the bracket should be located on the drag-link. Tighten stabilizer nut to 45ft-lbs. The above images are for reference use only (Fig.4 and 5). The images supplied show one stock height YJ and a 6" lifted TJ. You will need to determine the proper orientation for your vehicle set-up
- (5) (ALL) With steering wheel and steering knuckles aligned tighten the first keeper nut on all tie-rod ends. **NOTE: DO NOT TIGHTEN BOTH NUTS TOGETHER!** The first keeper nut must be tightened before starting the second nut. The assistance of a second person may be needed to insure that both of the first nuts are properly tightened on each tube (Fig.6). With the first nuts secured proceed with tightening the second set of keeper nuts. Again the assistance of a second person may be needed to insure that the second keeper nuts are properly tightened (Fig.7). Remember that the nuts must be tightened independently of each other for them to perform properly. If listed steps are not performed the keeper nuts could back out allowing the tubes to rotate and upsetting your alignment. **It is recommended that a quality thread lock be used (soft set).** After all nuts have been tightened double check to make sure no keeper nuts have loosened during the tightening procedure. Check all nuts at least 3 times.

Fig.6



Fig.7



**H/D Cross –Over steering conversion.
P/N: 18050.82 (XJ-TJ-ZJ) 18050.83 (1987-1995 YJ)**

WARNING: All KEEPER NUTS SHOULD BE INSPECTED PRIOR TO DRIVING TO INSURE THAT NONE HAVE LOOSEENED DURING INSTALLATION. Failure to tighten keeper nuts correctly can result in the tie-rod ends slowly backing out and upsetting your alignment. If not properly maintained and inspected damage may result. It is the owner's responsibility to check that all bolts and or keeper nuts are tight and with in listed torque specs after first 10-20 miles of driving and should be rechecked after 200 miles or after all off-road trips.

- (6) (ALL) After complete safety inspection proceed with road test avoiding traffic. Inspect bolts and tighten if needed. Have a certified 4WD shop or a qualified alignment shop perform the final alignment and double check all work performed for proper safety.

DISCLAIMER: Rugged Ridge – OMIX-ADA has supplied this part with the understanding that the purchaser is solely responsible for there vehicle and any modification made beyond original factory standards. Rugged Ridge – OMIX-ADA is not responsible for any injuries to the owner or damages to vehicle for improperly installed components, unsafe driving and or misuse of supplied components.



LIMITED 90 DAY WARRANTY
Applies to Rugged Ridge by Omix-ada Inc. Products

Rugged Ridge Off Road (the Company) warrants to the original purchaser of this product that should the product or any part thereof, under normal use and conditions, be proven defective in material or workmanship within 90 DAYS from the date of original purchase, such defect(s) will be repaired or replaced or credited at the Company's sole option.

To obtain repair or replacement within the terms of this Warranty, the product is to be delivered with proof of warranty coverage (e.g. Dated bill of sale), specification of defect(s) to the place of purchase or, with prior approval from the Company (Return Authorization Number is required), freight pre-paid to the Company address listed below.

This warranty does not apply to any product or part thereof which, in the opinion of the Company, has suffered or been damaged through alteration, improper installation, mishandling, misuse, neglect, accident or by acts of nature. THE EXTENT OF THE COMPANY'S LIABILITY UNDER THIS WARRANTY IS LIMITED TO THE REPAIR OR REPLACEMENT PROVIDED ABOVE AND, IN NO EVENT, SHALL THE COMPANY'S LIABILITY EXCEED THE PURCHASE PRICE PAID BY PURCHASER FOR THE PRODUCT.

This Warranty is in lieu of all express warranties or liabilities. ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY. ANY ACTION FOR BREACH OF ANY WARRANTY HEREUNDER INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY MUST BE BROUGHT WITHIN THE PERIOD OF 90 DAYS FROM DATE OF ORIGINAL PURCHASE.

IN NO CASE SHALL THE COMPANY BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER. No person or representative is authorized to assume for the Company any liability other than expressed herein in connection with the sale of this product.

Some States do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damage, so the above limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

Omix-ada Inc.
460 Horizon Dr. Suite 400
Suwanee, Georgia 30024