

Index No.	r Part No.	Description	No. Req'd.	Index No.	Part No.	Description	No. Req′d.
1	8940158894	Handle	1	18	8940158908	Inner Housing	1
2	8940158895	Stem-Throttle Valve	1	19	8940158909	Lock Nut	1
3	8940158896	O-Ring	1	20	8940158910	Plug Screw (NPT)	1
4	<u>8940158897</u>	O-Ring	1		8940161549	Plug Screw (PT)	
5	8940158898	Bushing-Valve	1	21	<u>8940158911</u>	Piston	1
6	8940158899	Spring-Valve	1	22	8940158912	Cylinder	1
7	8940158900	Triger-Throttle	1	23	8940158913	Valve	1
8	CA144843	O-Ring (2)	2	24	8940158914	Exhaust Deflector	1
9	CA146599	O-Ring (2)	2	25	<u>8940158915</u>	Retainer-Spring	1
10	8940158901	Pin-Grooved	1			(standard for CP7110)	
11	8940158414	Spring	1	26	CA156894	Decal-Warning Safety	1
12	8940158902	Air Inlet Tube	1	27	8940158924	Retainer-Quick Change	1
13	8940158903	Valve Seat	1			(standard for CP7110K)	
14	8940158904	O-Ring (2)	2			(Incl: 28, 29, 30)	
15	8940158905	Air Port	1	28	8940161843	Set Screw	3
16	8940158906	Bumper	1	29	8940161844	Ext. Retaining Ring	1
17	8940158907	Head-Inner Housing	1	30	8940161845	Int. Retaining Ring (Not Shown)	1



## CP7110 Shock Reduced Air Hammer

## **INSTRUCTION MANUAL**

#### Air Supply Requirements

- 1. Supply tool with 90 psig (6.2 bar) of clean, dry air. Higher pressure drastically reduces tool life.
- Connect tool to air line using pipe, hose, and fitting sizes shown in the diagram.



#### Lubrication

- Use an air line lubricator with SAE #10 oil, adjusted to two (2) drops per minute. If an air line lubricator cannot be used, add air motor oil to the inlet once a day.
- The use of synthetic oils for air line lubrication is not recommended because of possible damage to seals, o-rings, hose, rotor blades and polycarbonate oiler/filter bowls.

#### Operation

- 1. To insert chisel, press loop on retainer aside, push chisel into cylinder and release loop.
- 2. Place cutting edge of chisel against workpiece, depress trigger.

Acaution: Do not operate tool without chisel in cylinder, or allow the chisel to be driven out of cylinder. Internal damage will result if piston is allowed to strike cylinder wall.

#### Maintenance

- 1. Disassemble and inspect air motor every three months if the tool is used every day. Replace damaged or worn parts.
- 2. High wear parts are <u>underlined</u> in the parts list.
- Dirt or gum deposits cut tool power. To correct this, flush out the tool with gum solvent oil or an equal mixture of SAE #10 oil and kerosene. If outside conditions are in order, disassemble tool, replace worn or damaged parts, clean, reassemble and relubricate.

## EC DECLARATION OF CONFORMITY

We, Chicago Pneumatic Tool Company, 1800 Overview Drive, Rock Hill, SC 29730 USA, declare under our sole responsibility that the product to which this declaration relates, is in conformity with the requirements of the Council Directive of June 1998 on the approximation of the laws of the Member States relating to machinery (98/37/EC).

Machine Name CP7110 Shock Reduced Air Hammer Machine Type Power tool with .401 shank for use with chisel and various .401 shank accessories - No other use is permitted.

Serial No. Tools with No. 03268P or higher Technical Data

.401 in. (10 mm) shank Stroke 2-5/8 in. (66 mm) Air pressure 90 psi (6.2 bar) BPM 3200

Harmonized Standards Applied EN292 National Standards Applied ISO 8662-2, ISO15744-2002

Name And Position Of Issuer Yves Antier, General Manager, Chicago Pneumatic Tool Company

# Signature Of Issuer

Place And Date Of Issue Rock Hill, SC 29730 USA, October 31, 2003

#### **Noise & Vibration Declaration\***

Sound pressure level 98 dB(A), uncertainty 3 dB(A), in accordance with ISO 15744-2002. For sound power, add 11 dB(A).

Vibration value 9.0 m/s<sup>2</sup>, re. ISO 8662-2.

\*These declared values were obtained by laboratory type testing in compliance with the stated standards and are not adequate for use in risk assessments. Values measured in individual work places may be higher than the declared values. The actual exposure values and risk of harm experienced by an individual user are unique and depend upon the way the user works, the workpiece and the workstation design, as well as upon the exposure time and the physical condition of the user. We, Chicago Pneumatic, cannot be held liable for the consequences of using the declared values, instead of values reflecting the actual exposure, in an individual risk assessment in a work place situation over which we have no control.

#### Copyright 2004, Chicago Pneumatic Tool Company

All rights reserved. Any unauthorized use or copying of the contents or part thereof is prohibited. This applies in particular to trademarks, model denominations, part numbers and drawings. Use only authorized parts. Any damage or malfunction caused by the use of unauthorized parts is not covered by Warranty or Product Liability.



# A WARNING

To reduce risk of injury, everyone using, installing, repairing, maintaining, changing accessories on, or working near this tool must read and understand these instructions before performing any such task.

The goal of Chicago Pneumatic is to produce tools that help you work safely and efficiently. The most important safety device for this or any tool is YOU. Your care and good judgment are the best protection against injury. All possible hazards cannot be covered here, but we have tried to highlight some of the important ones.

#### For Additional Safety Information Consult:

- A Your employer, union and/or trade association.
- US Department of Labor (OSHA); www.osha.gov; Council of the European Communities europe.osha.eu.int
- A "Safety Code for Portable Air Tools" (ANSI B186.1) available from: www.ansi.org
- Safety Requirements for Hand-Held Non-Electric Power Tools" available from: European Committee for Standardization, www.cenorm.be

#### **Air Supply And Connection Hazards**

- Air under pressure can cause severe injury.
- A Always shut off air supply, drain hose of air pressure and disconnect tool from air supply when not in use, before changing accessories or when making repairs.
- Never direct air at yourself or anyone else.
- A Whipping hoses can cause serious injury. Always check for damaged or loose hoses and fittings.
- A Do not use quick disconnect couplings at tool. See instructions for correct setup.
- Whenever universal twist couplings are used, lock pins must be installed.
- Do not exceed maximum air pressure of 90 psi/6.2 bar or as stated on tool nameplate.

#### **Projectile Hazards**

- Always wear impact-resistant eye and face protection when involved with or near the operation, repair or maintenance of the tool or changing accessories on the tool.
- Be sure all others in the area are wearing impact-resistant eye and face protection.
- A Never operate a tool unless the accessory is retained in the tool with a proper retainer (see parts list).
- To avoid injury, retainer parts must be replaced when they become worn, cracked or distorted.
- A On overhead work, wear a safety helmet.

#### **Operating Hazards**

- To prevent damage to the tool and accessory, accessory must be held firmly against work surface before tool is throttled.
- Always shut off air supply, relieve hose of air pressure and disconnect tool from air supply when changing accessories.
- A Avoid direct contact with accessory and work surface during and after work as they become heated and sharp.
- Wear gloves to protect hands.
- A Operators and maintenance personnel must be physically able to handle the bulk, weight, and power of the tool.
- A Holding the accessory with the free hand can be a source of vibration exposure or injury.

#### Accessory Hazards

- A Never use any chisel as a hand struck tool. They are specifically designed and heat-treated to be used only in air hammers.
- A Select the correct shank and retainer for the tool being used.
- A Never use dull accessories as they require excessive work pressure and can break from fatigue.
- A Never cool a hot accessory in water. Brittleness and early failure can result.
- A This tool and its accessories must not be modified in any way.
- A Chicago Pneumatic hammers are not intended for use with any accessories that are not listed in the catalog.
- Accessory breakage or tool damage may result from prying. Take smaller bites to avoid getting struck.

#### Workplace Hazards

- A Slip/Trip/Fall is a major cause of serious injury or death. Be aware of excess hose left on the walking or work surface.
- High sound levels can cause permanent hearing loss. Use hearing protection as recommended by your employer or OSHA regulation (see 29 CFR part 1910).
- A Maintain a balanced body position and secure footing.
- Repetitive work motions, awkward positions and exposure to vibration can be harmful to hands and arms. If numbness, tingling, pain or whitening of the skin occurs, stop using tool and consult a physician.
- Avoid inhaling dust or handling debris from the work process which can be harmful to your health. Use dust extraction and wear respiratory protective equipment when working with materials which produce airborne particles.
- A Proceed with care in unfamiliar surroundings. Hidden hazards may exist, such as electric or other utility lines.
- A This tool is not intended for use in explosive atmospheres and is not insulated for contact with electric power sources.
- ▲ Some dust created by power sanding, sawing, grinding, drilling and other construction activities contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Some examples of these chemicals are:
  - Lead from lead based paints
  - Crystalline silica bricks and cement and other masonry products
  - And Arsenic and chromium from chemically-treated rubber

Your risk from these exposures varies, depending on how often you do this type of work. To reduce your exposure to these chemicals: work in a well ventilated area, and work with approved safety equipment, such as dust masks that are specially designed to filter out microscopic particles.

A For professional use only.

# **SAFETY INSTRUCTIONS** DO NOT DISCARD - GIVE TO USER