

Installation Guide

Installation Instructions to Assemble KM 1061 Uni Pro Seat & Suspension in John Deere 7000-7010 Series Tractors



- 1. Remove the original seat and suspension from the tractor along with the seat mounting plate. Keep mounting hardware for later use.
- If ordered with swivel install swivel at this time.NOTE: See install guide included with kit PN 5007.
- 3. Attach seat assembly to mounting plate PN 6077 as shown with tapered holes down. Install with four 8mm 1.25" x 20mm tapered bolts and four 8mm flange nuts.
- 4. Place seat into position in cab and use bolts and hardware removed in Step 1. to secure seat mounting plate into place.
- 5. To connect wiring use wiring harness or adapter included in attaching kit to plug and play on most models.

Phone: 1.800.328.1752 / Website: www.tractorseats.com

PN: 6077

