



Assembly Instructions

RESPIRATOR REPLACEMENT CARTRIDGES

Product number: SWX00325

Cartridge Assembly Instructions:

1. Line up notches on the cartridge with the notches on the facepiece, and push together.
2. Turn cartridge clockwise until it stops. Turn cartridge counter clockwise to remove.

Users must follow an appropriate cartridge change-out schedule developed by a qualified professional. The change-out schedule must take into account all factors that may influence respiratory protection including specific work practices and other conditions unique to the work environment.



Filter Replacement Instructions:

1. Remove filter retainer by lifting up on tab.
2. Place the filter into retainer so the printed side will face the cartridge. Securely snap retainer back onto cartridge insuring that the filter covers the entire cartridge surface.

See respirator instructions for specific limitations.



RETAIL PACKAGED
(SWX00325 - CLAMSHELL)