





DETAIL A-A

PLEASE NOTE:

- 1) FOR SAFE OPERATION AND CONTINUED HIGH PERFORMANCE FROM THIS EQUIPMENT, INSPECTION AND MAINTENANCE MUST BE PERFORMED BEFORE EACH USE.
- 2) USE OF THIS EQUIPMENT OTHER THAN INTENDED MAY BE HAZARDOUS.
- 3) ALTERATION OR MODIFICATION OF EQUIPMENT MAY BE HAZARDOUS. FOR REPAIR OR REPLACEMENT, PLEASE CALL YOUR DEALER.



**JAYPRO
SPORTS**

976 HARTFORD TURNPIKE
WATERFORD, CT 06385 USA
PHONE (800) 243-0533
FAX (800) 988-3363
WWW.JAYPRO.COM

DRAWN BY: J.A. / A.T./M.T. DATE: 6/5/2019

PRODUCT NAME:
PLAYER BENCH WITH SHELF

MODEL NO:
PBS-10/PBS-20/PBS-80/PBS-90

JAYPRO SPORTS
PLAYER BENCH WITH SHELF PBS-10/PBS-20/PBS-80/PBS-90
LIST OF MATERIALS

PIECE #	PART #	DESCRIPTION	PBS-10	PBS-20	PBS-80	PBS-90
1	AR5044	BOLT CLIP	32	24	16	40
2	AR5045A	END CAP	8	8	8	8
3	HB5030	5/16"-18 x 3" CARRIAGE BOLT	32	24	16	40
4	HN5046	5/16" FLANGE NUT	32	24	16	40
5	HS5035	#8 ZP PAN HEAD SCREW x 1/2"	16	16	16	16
6	EP0018	2" x 2" END PLUG	16	12	8	20
7A	AR5111	27' PLANK	N/A	N/A	N/A	4
7B	AR5052	21' PLANK	4	N/A	N/A	N/A
7C	AR5053	15' PLANK	N/A	4	N/A	N/A
7D	AR5079	7.5' PLANK	N/A	N/A	4	N/A
8	PBS-L	LEG FRAME	4	3	2	5

ASSEMBLY INSTRUCTIONS

TOOLS REQUIRED: Phillips Screwdriver Bit With Electric Drill (1),
 1/2" Socket Wrench or Adjustable Wrench (1)

- 1) Slip the end caps (2) snugly onto each end of each plank (7). Using the electric drill, assemble a self-drilling screw (5) through the cap and into the flange of the plank. Two screws are required per end cap. Carefully assemble 2" end caps (6) into bench legs (8).
- 2) For easiest assembly, position the shelf planks (7) on a flat level surface. Place the carriage bolt (3) and bolt clips (1) approximately into place within the slots of the plank. Note that the outside legs should be no more than 8" from the plank edge or 9" from edge to center of leg.
- 3) Position the legs (8) as shown and loosely assemble the hardware illustrated in detail 'A-A'. Do not fully tighten the hardware at this time.
- 4) Stand the unit upright and assemble the seat plank and backrest plank (7) as illustrated. Level the bench and make sure the legs are correctively spaced apart. Tighten all fasteners fully.

*Note: To anchor bench to a concrete base drill 2X 7/16" holes in each leg frame as shown. After assembled, anchor bench to concrete using a suitable concrete anchor (*not supplied*).

