


WHEELED TARGET STAND ASSEMBLY INSTRUCTIONS



To put together your target stand, you will need the following tools: (Not shipped with stand.)

Standard Screwdriver
Hammer

9.5mm. Wrench or Pliers

1. Refer to drawing above. Insert axle (#1) through one leg of brace (#3) and platform (#4).
2. Place one tube cap (#14) on mast (#2). Tube cap goes on end without hole for axle.
3. Slide axle (#1) through large hole in mast (#2) and through the other leg of platform (#4) and brace (#3).
4. Attach hinge (#5) to "inside" of brace (#3) and "outside" of platform (#4). Note that the hinge (#5) folds inward as shown on drawing. The short leg of the hinge (#5) must be attached to the brace (#3). USE # 10-M5*30mm long screws (#10) and #10-M5 locknuts (#11).
5. Tighten nuts (#11) so that hinges (#5) operate snugly...do not over tighten.
6. Assemble mast (#2) to middle of brace (#3) using #10-M5*56mm long screw (#15) and locknut (#11).
7. Now, assemble wheels. Slide three spacer washers (#6) on each end of axle (#1). Slide wheels (#7) onto axle (#1) and insert cotter pins (#8) into holes of axle (#1) and bend ends of cotter pin and tap hubcap (#9) onto ends of axle (#7) with hand.
8. Place tube caps (#14) on both ends of target cradles (#13).
9. Attach target cradles (#13) to platform (#4) using #10-M5 x 56mm screws (#15), locknuts (#11) and washers (#12). Washers go between cradle (#13) and platform (#4).
10. Attach handle (#16) to top of mast (#2) with prongs on handle toward inside of target stand. (See drawing). Secure with two # 10-M5 x 56mm screws (#15) and locknuts (#11).

Note: Handle (#16) has two sets of holes for attaching to mast. When stand is to be used for large targets, use the set of holes farthest from bend in handle. This will raise the handle.