



Tech

Specially treated to dissipate static and safely absorb volatile fuels and other petroleum-based liquids.

- Use where static electricity is a problem or where vapors can ignite
- A safer alternative for cold applications, low humidity climates or dry environments
- Mat has many applications in aviation industry where jet fuel is present and the utility industry for electrical work
- Single-layer polypropylene absorbs fast for quick response
- Oil selective repels water but absorbs oil and all oil-based fluids
- Packaged in blue static-dissipative bag for quick identification

WPX50H Specifications

Spill

Dimensions:	15" W x 19" L
Shipping	15" W x 19" L x 8" H
Dimensions:	
Sold as:	50 pads per package
Color:	White
Composition:	Polypropylene
Absorbency:	Up to 16.8 gal. per package
Absorbency per:	Up to 43.01 oz. per pad
Weight:	6.5 lbs.
# per Pallet:	60
Incinerable:	Yes
Ship Class:	175

Metric Equivalent Specifications

Dimensions:	38.1cm W x 48.3cm L
Shipping	38.1cm W x 48.3cm L x 20.3cm H
Dimensions:	
Absorbency:	Up to 63.6 L per package
Absorbency per:	Up to 1.3 L per pad
Weight:	2.9 kg



Online: spilltech.com





Email: sales@spilltech.com

WPX50H Technical Information

Warnings & Restrictions:

There are no known warnings and restrictions for this product.

Regulations and Compliance:

49 CFR 173.3(c)(2) - The area between a container and a salvage drum used for overpacking must have "sufficient cushioning and absorption material to prevent excessive movement of the damaged package and to eliminate the presence of any free liquid at the time the salvage drum is closed."

40 CFR 263.31 - Transporters, "must clean up any hazardous waste discharge that occurs during transportation...so that the hazardous waste discharge no longer presents a hazard to human health or the environment."

40 CFR 263.30(a) - In the event of a spill, transporters must, "take appropriate immediate action to protect human health and the environment."

29 CFR 1910.22(a)(2) - Floors in your workplace should be, "maintained in a clean and, so far as possible, a dry condition."

29 CFR 1910.1450(e) - OSHA requires containment and cleanup materials for spills in laboratories to reduce occupational exposure to hazardous chemicals.

29 CFR 1910.120(j)(1) - Under an OSHA requirement, "DOT-specified salvage drums or containers and suitable quantities of proper absorbents shall be kept available and used in areas where spills, leaks, or ruptures may occur."

Technical Documents:

(Available at spilltech.com) Product Data Sheet (PDS) Safety Data Sheet (SDS)





Fax: 1-800-872-3764 (N.Am.) 1-770-410-1812 (Other) Email: sales@spilltech.com