


**ASSEMBLY INSTRUCTIONS**

- 1) Dig hole approximately 12" dia x 24" deep.
- 2) Place 1/2" Ø Rod (**item C**) thru hole in bottom of Pole (**item B**). Place pole in the 24" deep hole and plumb. Support Pole while pouring concrete.
- 3) After pouring concrete, check to insure Post is still plumb.
- 4) Concrete must cure at least 48 hours before completing rest of assembly.
- 5) Install Eye Bolt (**item D**) in top of Pole (**item A**). Secure with the 3/8" Locknut (**item E**).
- 6) Slip Pole (**item A**) over Pole (**item B**) and line up the holes. Secure with the 5/16" x 2 3/4" Bolt and Locknut (**items F and G**).



ITEM	DESCRIPTION	QTY
A	TOP POLE	1 EA.
B	BOTTOM POLE	1 EA.
C	1/2" DIA ROD x 6" LONG	1 EA.
D	3/8" x 2 1/2" EYE BOLT	1 EA.
E	3/8" NYLOC NUT	1 EA.
F	5/16" x 2 3/4" HEX BOLT	1 EA.
G	5/16" NYLOC NUT	1 EA.
H	PLASTIC CAP	1 EA.

THIS WARNING IS GIVEN IN COMPLIANCE  
WITH CALIFORNIA PROPOSITION 65:

**WARNING**

This product may contain chemicals known to the  
State of California to cause cancer, birth defects  
or other reproductive harm.

**NOTE:**  
Place a block, brick or stone  
at the bottom to help stabilize post  
and prevent it from sinking into the dirt.