


PLEASE NOTE:

- 1) FOR SAFE OPERATION AND CONTINUED HIGH PERFORMANCE FROM THIS EQUIPMENT, INSPECTION AND MAINTENANCE MUST BE PERFORMED BEFORE EACH USE
- 2) USE OF THIS EQUIPMENT OTHER THAN INTENDED, MAY BE HAZARDOUS.
- 3) ALTERATION OR MODIFICATION OF EQUIPMENT MAY BE HAZARDOUS. FOR REPAIR OR REPLACEMENT, PLEASE CALL YOUR DEALER

NOTE: PUSH TUBE CONNECTOR APPROX. 1/2" INTO REAR SIDEFRA

VIEW A-A



Jaypro Sports

976 Hartford Turnpike
Waterford, CT 06385 USA
(800)243-0533
(800)988-3363 Fax
www.jaypro.com

MODEL NO.:

AT-5

PRODUCT NAME:

ALL TERRAIN TE-2

DRAWN BY: JAC

EFFECTIVE DATE:
10-11-12

JAYPRO SPORTS
ALL TERRAIN TE-2, AT-5
LIST OF MATERIALS

<u>PIECE NO.</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>QTY.</u>
1	TE21	EQUIPMENT TOTEMASTER	1
2	AT1	M12 x 75mm LONG HEX HEAD SCREW	2
3	RW5006	12" x 1 3/4" RIB WHEEL 1/2"BB	2
4	AT2	M12 HEX NUT	2
5	AT3	M6 x 30 mm LONG HEX HEAD SCREW	2
6	AT4	M6 INSERT NUT	2
7	AT5	M12 THREADED ROD	1
8	CS0008	CASTER SWIVEL 7/16" x 1 3/8"	2
9	AT6	M12 COUPLING NUT	2

ASSEMBLY INSTRUCTIONS

TO CONVERT THE STANDARD MODEL CARRIER TO THE "ALL TERRAIN" STYLE, FOLLOW THE INSTRUCTIONS PROVIDED BELOW CAREFULLY.

TOOLS REQUIRED: SMALL HAMMER (1)

FLAT BLADE STANDARD SCREWDRIVER (1)

SMALL ADJUSTABLE WRENCH (1)

- 1) OPEN THE TOTEMASTER BOX (MODEL TE-2), REMOVE THE CONTENTS AND FOLD OPEN THE CARRIER.
- 2) PUSH THE TWO SWIVEL CASTERS (8) INTO THE PLASTIC SOCKETS ALREADY INSERTED INTO THE FRAME. SEAT CASTERS FIRMLY TO "LOCK" IN PLACE. THIS IS THE FRONT OF THE CARRIER.
- 3) FOR THE REAR SIDE OF THE CARRIER IT IS NECESSARY TO REMOVE THE PLASTIC SOCKETS. USING THE SCREWDRIVER AND HAMMER, GENTLY TAP THE SOCKET HEAD TO WORK IT LOOSE FROM THE FRAME. THE REMOVED SOCKETS MAY BE DISCHARGED.
- 4) PUSH ONE TUBE CONNECTOR (6) APPROXIMATELY 1/2" INTO THE OPEN END OF THE REAR SIDE FRAME. NOTE THAT THE CONNECTORS ARE SLIGHTLY CONCAVE. THIS ALLOWS THE CONNECTOR TO PUSH INTO THE FRAME BUT NOT PULL OUT. FOR BEST RESULTS, THREAD ONE OF THE M6 x 30 mm LONG HEX HEAD SCREWS (5) INTO THE CONCAVE SIDE OF THE CONNECTOR, PLACE IT OVER THE OPEN END OF THE REAR SIDE FRAME AND GENTLY TAP THE HEAD OF THE SCREW UNTIL THE CONNECTOR IS SEATED AT THE PROPER DEPTH. REMOVE THE SCREW AND THE CONNECTOR WILL HOLD ITS POSITION.
- 5) THREAD A COUPLING NUT (9) APPROXIMATELY 1/2" ONTO EACH END OF THE THREADED ROD (7). NEXT, ATTACH THIS THREADED ROD ASSEMBLY ONTO THE REAR SIDE OF THE CARRIER USING THE M6 x 30 mm LONG HEX HEAD BOLTS (5). IT WILL BE NECESSARY TO ADJUST THE COUPLING NUTS SLIGHTLY TO GET PROPER MOUNTING HOLE ALIGNMENT WITH THE TUBE CONNECTORS.
- 6) SLIP THE M12 x 70 mm LONG HEX HEAD SCREW (2) THROUGH THE CENTER OF THE WHEEL (3) THEN THREAD ON A M12 HEX NUT (4).
- 7) HAND TIGHTEN WHEEL ASSEMBLY INTO COUPLING NUT (9). NEXT, USING A WRENCH, FIRMLY TIGHTEN HEX NUT (4) TO COUPLING NUT (9). FIRMLY TIGHTEN HEX HEAD SCREW (2) INTO COUPLING NUT (10) USING WRENCH. (SEE ILLUSTRATION VIEW B-B). CHECK THAT WHEELS (3) SPIN FREELY.