PULLERS

GEAR PULLERS

Forged from alloy, heat-treated steel, with fine-threaded center screws for extra pulling power. Jaws are adjustable and/or reversible to broaden applications.

2-JAW	ADJUSTAI	BLE/REVE	RSIBLE	
No.	Spread	Reach	Screw Length	Capacity
8000*	4"	3-1/2"	5"	2 Tons
8010*	7"	5-1/2"	7"	5 Tons
2-JAW REVERSIBLE				
No.	Spread	Reach	Screw Length	Capacity
8005*	6"	3-1/2"	7"	5 Tons
8015 *	9"	5-1/2"	9"	7 Tons
2-JAW ADJUSTABLE				
No.	Spread	Reach	Screw Length	Capacity
8020	10"	9"	9"	7 Tons
8025	12"	11"	13"	13 Tons
8030	15"	15"	13"	13 Tons
3-JAW ADJUSTABLE/REVERSIBLE				
No.	Spread	Reach	Screw Length	Capacity
8035*	4"	3-1/2"	5"	2 Tons
8045*	8"	5-1/2"	7"	5 Tons
3-JAW REVERSIBLE				
No.	Spread	Reach	Screw Length	Capacity
8040*	7"	3-1/2"	7"	5 Tons
8050*	10"	5-1/2"	9"	7 Tons
3-JAW	ADJUSTAI	BLE/REVE	RSIBLE	
No.	Spread	Reach	Screw Length	Capacity
8055	11"	9"	9"	7 Tons
8057	14"	11"	13"	13 Tons
8059	17"	15"	13"	13 Tons
* -				

* Packed in clamshell. Add "B" for Bulk Pack. All others packed in box.



8035-8045

8040-8050 8097 LARGE GEAR & PULLEY PULLER Remove parts w/ tapped holes with 8-1/4" (21cm) yoke and 11-5/8" (30cm) long forcing screw.



8095 TIMING GEAR PULLER

8490 THIN-JAW PULLER SET

For use in tight spaces. Includes 3 pairs

8"(200mm) & 10" (250mm) w/ hardened

of different length arms: 4" (100mm),

thin-jaw attachments.

Puller spreads from 2" to 7 3/4" (5 to 20cm).

Pull parts w/ two tapped holes, including gears, fan pulleys, balancers & cam gears. Cross-arm is 1" square and 5" long, with 3/8" - 16 side bolts.



8494 THIN-JAW BEARING REMOVER For use in tight spaces. 3.5" (9cm) long hardened jaws. Adjusting width from 1.2" - 3.5" (3cm - 9cm).



8099 PUSH PULLER

For use w/ bearing splitters when removing & installing gears, bearings, shafts, pulleys & other press-fit parts. Capacity: 10 Tons Spread: 2-1/8 to 7-1/4" Screw Size: 3/4 - 16 x 12 Reach: 8-1/4"

BEARING SEPARATORS

Remove generator gears, bearings, bearing cones & similar parts where ordinary puller jaws will not reach. Knife-like edges minimize damage. No. Range 8060 Up to 2-1/4" (57mm) Up to 4-1/4" (108mm) 8065 Up to 6" (150mm) 8150 Up to 8" (200mm) 8155





8492 INTERNAL BEARING **REMOVER SET**

Removes captured bearings, pilot bearings, bushings, etc. Includes Puller, 11" (29cm) slide hammer, 5 expanding adapters & 3 attachments: M6 x 1.0P. M8 x 1.25P. M10 x 1.5P. Working range is 8-34mm diameter.



8070L PILOT BEARING PULLER - SCREW TYPE

Removes fly wheel pilot bearings &					
bushings up to 7-1/2" (19cm long).					
Better control for precision pulling					
in tight areas. Replacement Jaws:					
No.	Description				
8070X06	1/2 to 1-1/2" (13-38mm I.D.)				
8070X07	3/8 to 1-3/8" (9.5-35mm I.D.)				



8075 PILOT BEARING PULLER - W/ SLIDE HAMMER For inside pulling jobs, jaws will remove flywheel pilot & other bearings. Range: 1/2" to 1-1/2" (13-38mm). OAL: 17.75" (45cm).

8077 PILOT BEARING PULLER - W/ SLIDE HAMMER For inside pulling jobs, jaws will remove flywheel pilot & other bearings. Range: 1/2" to 1-1/2" (13-38mm). OAL: 20.5" (52.1cm).



8092 SLIDE HAMMER PULLER Remove bearings, gears, bushings & more. 5 lb. hammer & 3-Jaw assembly.



8090 SLIDE HAMMER PULLER KIT

Remove bearings, gears, bushings, seals, grease retainers, etc. Includes 4 iaw assemblies for internal & external & 2/3 jaw pulling.



3 jaw range: 1-1/2 to 4-1/2" (38-114mm) outside, 1-5/16 to 4-3/4" (33-121mm) inside. 2 jaw range: 1 to 4-1/2" (25-114mm) outside, 1-1/4 to 3-3/8" (32-86mm) inside.

A490 8-WAY SLIDE HAMMER PULLER SET

Service rear axle, bearings, oil seals & press-fit parts. Includes reversible jaws for internal/external work, 3 jaws,

cone & other adapters. 5/8" - 18 thread.

1550 FLANGE-TYPE PULLER SET Two yoke sizes & 4 sets of side screws for all types of pulling jobs. Use for gears, harmonic balancers, pulleys, steering wheels & more! Also includes 2 center screws & 2 swivel tips.



5 lb. slide hammer, rear axle pulling plate, screw, hook, dent puller adapter,

Visit ctatools.com for application details