



199R7449




NOTE: Make sure top surface of vent baffle is not depressed after installation of drive screw. Do not permit baffle to sag and contact float, or flooding will result. Stake the metering body beneath the baffle to raise, if necessary.

199R7449




NOTE: Make sure top surface of vent baffle is not depressed after installation of drive screw. Do not permit baffle to sag and contact float, or flooding will result. Stake the metering body beneath the baffle to raise, if necessary.

199R7449




NOTE: Make sure top surface of vent baffle is not depressed after installation of drive screw. Do not permit baffle to sag and contact float, or flooding will result. Stake the metering body beneath the baffle to raise, if necessary.

199R7449




NOTE: Make sure top surface of vent baffle is not depressed after installation of drive screw. Do not permit baffle to sag and contact float, or flooding will result. Stake the metering body beneath the baffle to raise, if necessary.

199R7449



NOTE: Make sure top surface of vent baffle is not depressed after installation of drive screw. Do not permit baffle to sag and contact float, or flooding will result. Stake the metering body beneath the baffle to raise, if necessary.

199R7449



NOTE: Make sure top surface of vent baffle is not depressed after installation of drive screw. Do not permit baffle to sag and contact float, or flooding will result. Stake the metering body beneath the baffle to raise, if necessary.