

# Oil-Only Responder™ Roll #WR300S - 30" x 300', 1 roll/package



Economical MeltBlown mat for effective oil response

- · Best performing mat on water due to fast-wicking fibers
- Highly absorbent MeltBlown polypropylene mat repels water and soaks up only oil and oil-based fluids
- Floats even when completely saturated most effective for marine spills
- Bright white color makes it easy to locate in spill emergencies
- Won't fall apart even when fully saturated
- Rolls are ideal for covering large areas

## **WR300S Specifications**

**Dimensions:** 30" W x 300' L

**Shipping** 17" W x 30" L x 17" H

**Dimensions:** 

Sold as: 1 roll per package

Color: White

Composition: Polypropylene

**Absorbency:** Up to 67.9 gal. per package

Weight: 28.7 lbs.

# per Pallet: 15

Basis Weight: SingleWeight

Incinerable: Yes Ship Class: 175

## **Metric Equivalent Specifications**

**Dimensions:** 76.2cm W x 91m L

**Shipping** 43.2cm W x 76.2cm L x 43.2cm H

**Dimensions:** 

**Absorbency:** Up to 257 L per package

Weight: 13 kg



Phone: 1-800-228-3877 (N.Am.) 1-770-475-3877 (Other) Fax: 1-800-872-3764 (N.Am.) 1-770-410-1812 (Other) Email: sales@spilltech.com

## **WR300S Technical Information**

### Warnings & Restrictions:

There are no known warnings and restrictions for this product.

### **Regulations and Compliance:**

49 CFR 173.3(c)(2) - The area between a container and a salvage drum used for overpacking must have "sufficient cushioning and absorption material to prevent excessive movement of the damaged package and to eliminate the presence of any free liquid at the time the salvage drum is closed."

40 CFR 263.31 - Transporters, "must clean up any hazardous waste discharge that occurs during transportation...so that the hazardous waste discharge no longer presents a hazard to human health or the environment."

40 CFR 263.30(a) - In the event of a spill, transporters must, "take appropriate immediate action to protect human health and the environment."

29 CFR 1910.22(a)(2) - Floors in your workplace should be, "maintained in a clean and, so far as possible, a dry condition."

29 CFR 1910.1450(e) - OSHA requires containment and cleanup materials for spills in laboratories to reduce occupational exposure to hazardous chemicals.

29 CFR 1910.120(j)(1) - Under an OSHA requirement, "DOT-specified salvage drums or containers and suitable quantities of proper absorbents shall be kept available and used in areas where spills, leaks, or ruptures may occur."

#### **Technical Documents:**

(Available at spilltech.com)
Product Data Sheet (PDS)
Safety Data Sheet (SDS)

